

GLECO TRAP® SYSTEM (64 oz.)

Plaster Trap

Make changing your plaster trap a clean, effortless task.

Invented by a plumber, the Gleco Trap brings innovation to the age-old chore of sink trap retrieval and plaster trap maintenance.

Install the pre-assembled Gleco Trap once, then replacing the bottle takes less than one minute start to finish without tools. Simply turn side valve to drain off excess water, unscrew full bottle, and screw in a clean one.

- Side drain siphons out all water prior to removal, eliminating spillage.
- See-through bottle shows waste level.
- Adapts easily to existing plumbing—the Gleco Trap is the only plaster trap to meet **US Uniform Plumbing Code!**

System includes one trap assembly, two 64 oz. replacement bottles, all necessary 1½" pipe components and simple instructions for a five-minute installation.

10012 GT-64 Gleco Trap System (64 oz.)

10016 GT-32C 32 oz. Replacement Bottles - case of 12

10017 GT-43C 43 oz. Replacement Bottles - case of 6

10013 GT-64C 64 oz. Replacement Bottles - case of 6

10015 GT-128C 128 oz. Replacement Bottles - case of 4

10090 Gleco Gasket - pack of 2



1. Drain water

2. Remove bottle

3. Replace

GLECO TRAP