



## For Your Active Lifestyle

Ultraleather™ has the durability and strength to stand up to your active lifestyle. It meets or surpasses industry wear standards including bond strength, seam strength and tear strength. Ultraleather exceeds 400,000 double rubs on the Wyzenbeek abrasion test method showing no wear and tear—that's 13X heavy-duty industry standards.

## You've Only Touched the Surface

Ultraleather stays cool to the touch, even when exposed to sunlight. Soft and supple, Ultraleather is tough enough to withstand kids and pets. Because it's inherently stain-resistant, no toxic aftercare is required to keep Ultraleather looking its best.

## Earth Friendly

- Greenguard® Certified
- No PVC (Polyvinyl Chloride)
- No POPs (Persistent Organic Pollutants)
- No PBDEs (Polybrominated Diphenyl Ethers)
- No HFRs (Halogenated Flame Retardants)
- Meets the most stringent VOC standards
- No Plasticizers, Heavy Metals, Stabilizers, Phthalates or Bisphenol A (BPA)
- No toxic by-products
- Over 99% of solvents recaptured and recycled
- ISO 9001 Certified Mill

## Maintenance & Care Instructions

Keep Ultrafabrics, LLC brand surfaces looking great by routine and proper maintenance. Clean regularly to prevent excessive dirt from accumulating. Follow these guidelines to extend the life of the fabric:

- Clean regularly with soap and water
- Wipe up spills as soon as they occur
- Remove stains with alcohol-based cleaners like Fantastik® and Formula 409®
- Clean/disinfect using a 5:1 water/bleach solution or a commonly used healthcare disinfectant, such as CaviCide® and Virox®
- Thoroughly rinse all solution residue with water
- Air dry

For more detailed information, visit us on the web at [www.ultrafabricsllc.com](http://www.ultrafabricsllc.com)

## SPECIFICATIONS

### ISO 9001-CERTIFIED PRODUCTION FACILITY

COMPOSITION:	100% POLYURETHANE SURFACE WITH 100% REINFORCED RAYON BACKING
WEIGHT:	APPROX. 9.7 OZ. PER SQUARE YD (APPROX. 330 GRAMS PER SQUARE METRE) APPROX. 14.6 OZ. PER LINEAR YD (APPROX. 450 GRAMS PER LINEAR METRE)
THICKNESS:	APPROX. 0.95 MM
WIDTH:	54 INCHES / 137 CENTIMETRES
PUT-UP:	APPROX. 33 YDS / 30 METRES R.O.T.

### CHARACTERISTICS (MEETS OR EXCEEDS)

ABRASION:	ASTM D 4157 / 400,000 DOUBLE RUBS* BS 2543 / 180,000 RUBS** <small>*WYZENBEEK **MARTINDALE</small>
TENSILE STRENGTH:	ASTM D 1117
TEAR STRENGTH:	ASTM D 1117
DIMENSIONAL CHANGE:	ASTM D 3597
SEAM STRENGTH:	ASTM D 751
STRETCH & SET:	SAE J855

### COLORFASTNESS

CROCKING:	AATCC 8, CLASS 5 WET & DRY
LIGHT	AATCC 16E, AATCC 16A, CLASS 5 ISO 105 - B02 : 1999 GRADE 7/8
GAS:	AATCC 23, CLASS 5
OZONE:	AATCC 109, CLASS 5

### F/R RATING (HFR FREE)

ASTM E 84 (ADHERED)	CLASS A
CA 117 E	CLASS 1
FMVSS 302 & 95/28 ANNEX IV	PASS
NFPA 260	CLASS 1
UFAC	CLASS 1

• CAN BE TREATED TO MEET FAR SPECIFICATIONS.  
• THIS FABRIC, WHEN TREATED AND/OR USED WITH OTHER COMPATIBLE FURNITURE COMPONENTS, HAS BEEN SHOWN TO PERFORM WELL UNDER THE FIRE TEST CONDITIONS OF CALIFORNIA TECHNICAL BULLETIN 133, BS 5852 PT 0, 1 & 5 (CRIB 5), IMO A.652 (16), BS 7175 AND BS 5867 PART 2 TYPE B.



Scan code to place sample request



## CRAFTED INTELLIGENCE.

Ultrafabrics, LLC | Hudson Point, 303 South Broadway | Tarrytown, NY 10591 | USA | T 914.460.1730 | F 914.631.3572 | [www.ultrafabricsllc.com](http://www.ultrafabricsllc.com)  
Ultrafabrics Europe Ltd. | 19 The Warren, East Goscote | Leicestershire, LE7 3XA | United Kingdom | T +44.116.260.9625 | [ufe@ultrafabricsllc.com](mailto:ufe@ultrafabricsllc.com)  
Made in Japan. Ultraleather™, Brisa® and Promessa® are trademarks of Ultrafabrics, LLC.

7/12

